



## Installation Instructions: Ford Super Duty 99-01 - Gauge Pod



Model# 15003 (Double sided tape)

1. Test fit pod in dash with gauges installed to assure clearance.
2. Install gauges in bezel. Following gauge installation instructions, run wiring down between dash and instrument cluster.
3. Cut tape into 5 separate 3 inch sections.
4. Clean factory bezel and back of gauge pod with glass cleaner where tape will be applied.
5. Place tape on pod.
6. Peel backing from tape and install Gauge pod. Try to align the bridge behind the steering column first. This will align the entire pod to the dash.

---

Please contact Speedhut service department If you have a problem with this Product.

Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com



## Installation Instructions: Ford Super Duty 99-01 - Gauge Pod



Model# 15003 (Double sided tape)

1. Test fit pod in dash with gauges installed to assure clearance.
2. Install gauges in bezel. Following gauge installation instructions, run wiring down between dash and instrument cluster.
3. Cut tape into 5 separate 3 inch sections.
4. Clean factory bezel and back of gauge pod with glass cleaner where tape will be applied.
5. Place tape on pod.
6. Peel backing from tape and install Gauge pod. Try to align the bridge behind the steering column first. This will align the entire pod to the dash.

---

Please contact Speedhut service department If you have a problem with this Product.

Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com