

Model #15022 is designed to fit 2002-2006 Hummer H2 (instructions only)

STEP ONE: Remove the two allen screws on the lower left and right of the vent cover.

STEP TWO: Pull straight back on cover. Carefully use a screwdriver or putty knife at the rear of the cover to apply forward pressure.

STEP THREE: Wire and install gauges into pod. The gauges are a pressure fit and do not require additional brackets or hardware to hold them into the pod.

STEP FOUR: Run wiring through the cutout located on the left side of the pod.

STEP FIVE: Place pod on dash and press down on back to snap pod in place.

STEP SIX: Reinstall the vent cover over the front lip of the pod. Be sure the pins on the back of the cover are in the holes on the dash and the allen screws are reinstalled.

NOTE: due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”

www.Speedhut.com **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460

Model #15022 is designed to fit 2002-2006 Hummer H2 (instructions only)

STEP ONE: Remove the two allen screws on the lower left and right of the vent cover.

STEP TWO: Pull straight back on cover. Carefully use a screwdriver or putty knife at the rear of the cover to apply forward pressure.

STEP THREE: Wire and install gauges into pod. The gauges are a pressure fit and do not require additional brackets or hardware to hold them into the pod.

STEP FOUR: Run wiring through the cutout located on the left side of the pod.

STEP FIVE: Place pod on dash and press down on back to snap pod in place.

STEP SIX: Reinstall the vent cover over the front lip of the pod. Be sure the pins on the back of the cover are in the holes on the dash and the allen screws are reinstalled.

NOTE: due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”

www.Speedhut.com **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460