

***SPEEDHUT*** Gauge Pod      Installation Instructions: 07+ Chevy/GMC Pillar  
Models #17115, #17116, #17117, and #17118 (needs screw)

**STEP ONE:** Remove stock pillar.

-Screw is located under the cap at the top of the pillar.

**STEP TWO:** Install gauges in new “replacement” pillar.

**STEP THREE:** Tape or secure gauge wiring to back of new pillar.

**STEP FOUR:** Install new pillar in Truck.

**STEP FIVE:** Use provided screw to hold new pillar in place.

- Don't over tighten the screw.

[www.Speedhut.com](http://www.Speedhut.com) **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460

***SPEEDHUT*** Gauge Pod      Installation Instructions: 07+ Chevy/GMC Pillar  
Models #17115, #17116, #17117, and #17118 (needs screw)

**STEP ONE:** Remove stock pillar.

-Screw is located under the cap at the top of the pillar.

**STEP TWO:** Install gauges in new “replacement” pillar.

**STEP THREE:** Tape or secure gauge wiring to back of new pillar.

**STEP FOUR:** Install new pillar in Truck.

**STEP FIVE:** Use provided screw to hold new pillar in place.

- Don't over tighten the screw.

[www.Speedhut.com](http://www.Speedhut.com) **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460