

Models #17212, #17213 is designed to fit 2003+ Dodge Ram (1 long bolt)

Models #17218, #17219 designed to fit 2010+ Dodge Ram (1 short bolt)

**STEP ONE:** Remove stock pillar.

**STEP TWO:** Install gauges in new pillar.

**STEP THREE:** Tape or secure gauge wiring to back of new pillar.

**STEP FOUR:** Install new pillar in place of old pillar.

**STEP FIVE:** Use provided screw to hold new pillar in place:

- Make sure screw is aligned with factory hole to avoid cross threading.
- Don't over tighten the screw.

[www.Speedhut.com](http://www.Speedhut.com) **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460

Models #17212, #17213 is designed to fit 2003+ Dodge Ram (1 long bolt)

Models #17218, #17219 designed to fit 2010+ Dodge Ram (1 short bolt)

**STEP ONE:** Remove stock pillar.

**STEP TWO:** Install gauges in new pillar.

**STEP THREE:** Tape or secure gauge wiring to back of new pillar.

**STEP FOUR:** Install new pillar in place of old pillar.

**STEP FIVE:** Use provided screw to hold new pillar in place:

- Make sure screw is aligned with factory hole to avoid cross threading.
- Don't over tighten the screw.

[www.Speedhut.com](http://www.Speedhut.com) **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460