

Models #17312, #17313 is designed to fit 2008+ Ford Super Duty (2 short bolts)

STEP ONE: Remove the four screws located under the caps of pillar handle.

STEP TWO: Install gauges and wiring in new pillar.

-Openings for wiring may need to be created in the factory pillar

STEP THREE: The new pillar should fit perfectly over the factory pillar.

-Make sure wiring isn't interfering with the fit

STEP FOUR: Use the provided screws to hold pillar in place.

-Don't over tighten the screws...snug only

www.Speedhut.com **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460

Models #17312, #17313 is designed to fit 2008+ Ford Super Duty (2 short bolts)

STEP ONE: Remove the four screws located under the caps of pillar handle.

STEP TWO: Install gauges and wiring in new pillar.

-Openings for wiring may need to be created in the factory pillar

STEP THREE: The new pillar should fit perfectly over the factory pillar.

-Make sure wiring isn't interfering with the fit

STEP FOUR: Use the provided screws to hold pillar in place.

-Don't over tighten the screws...snug only

www.Speedhut.com **Need help?** Contact us: Speedhut Inc. 165 North 1330 West B2 Orem, Utah 84057 or call 801-221-1460