



Installation Instructions: Honda Civic 96-01, Acura Integra 94-00 - Gauge Pod

Model# 20010 (bracket and small bolt)  
Model# 20011 (Small bracket, small bolt, nut)

1. Remove stock gauge bezel.
2. **ACURA INTEGRA** - Drill 7/64" hole in the plastic cross member. Install aluminum bracket. Bracket stud should align with hole in lower center of gauge pod.  
**HONDA CIVIC** - Remove bottom center screw from gauge cluster housing. Reinstall screw and supplied aluminum bracket.
3. Install gauges in new gauge pod (gauges are press fit).
4. Install new gauge pod using original screws in the top.
5. Attach bottom of pod to aluminum bracket using supplied hardware.
6. Run gauge wiring out through the firewall.

---

Please contact Speedhut service department If you have a problem with this Product.  
Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com



Installation Instructions: Honda Civic 96-01, Acura Integra 94-00 - Gauge Pod

Model# 20010 (bracket and small bolt)  
Model# 20011 (Small bracket, small bolt, nut)

1. Remove stock gauge bezel.
2. **ACURA INTEGRA** - Drill 7/64" hole in the plastic cross member. Install aluminum bracket. Bracket stud should align with hole in lower center of gauge pod.  
**HONDA CIVIC** - Remove bottom center screw from gauge cluster housing. Reinstall screw and supplied aluminum bracket.
3. Install gauges in new gauge pod (gauges are press fit).
4. Install new gauge pod using original screws in the top.
5. Attach bottom of pod to aluminum bracket using supplied hardware.
6. Run gauge wiring out through the firewall.

---

Please contact Speedhut service department If you have a problem with this Product.  
Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com