



Installation Instructions: Glove Box Mount Pod



Model# 20030 and 20032 (large ratchet fasteners and double sided tape)

1. Place pod in glove box and drill a 1/4" hole where each of the four tabs are located.
2. Install gauges and accessories in pod.
3. There are several 1/4" DIN locations marked "Cut Out" that can be utilized to mount Turbo Timers and Boost controllers. Use provided tape to secure units to mounting tabs.
4. Push in ratchet fasteners (Make sure the back edge of glove box is in the channel).

Please contact Speedhut service department If you have a problem with this Product.

Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com



Installation Instructions: Glove Box Mount Pod



Model# 20030 and 20032 (large ratchet fasteners and double sided tape)

1. Place pod in glove box and drill a 1/4" hole where each of the four tabs are located.
2. Install gauges and accessories in pod.
3. There are several 1/4" DIN locations marked "Cut Out" that can be utilized to mount Turbo Timers and Boost controllers. Use provided tape to secure units to mounting tabs.
4. Push in ratchet fasteners (Make sure the back edge of glove box is in the channel).

Please contact Speedhut service department If you have a problem with this Product.

Speedhut Inc. 165 North 1330 West B2, Orem, Utah 84057 | support@speedhut.com | (801) 221-1460 (9am - 5pm MST) | www.Speedhut.com